



QT608C

Quantec Corridor Display



Overview

A16 character x 2 line display used to indicate incoming calls in corridors, staff rooms, nursing stations, etc.

Includes an onboard sounder and buttons to accept, scroll through and manually divert calls.

Shows call type, call location and (depending on the device used to make the call) the User ID or name of the person calling.

Highest priority calls are shown first with a message saying how many calls are waiting.

Flash and sound rates intensify to reflect the urgency of incoming calls.

Adjustable contrast and volume controls.

External sounder connection.

QT608CD

Quantec Corridor Display (no controls)



Overview

A 16 character x 2 line display used to indicate incoming calls in corridors, staff rooms, nursing stations, etc.

Shows call type, call location and (depending on the device used to make the call) the User ID or name of the person calling.

Highest priority calls are shown first with a message saying how many calls are waiting.

Flash and sound rates intensify to reflect the urgency of incoming calls.

Adjustable contrast and volume controls.

External sounder connection.

QT608CD1S

Quantec Large Corridor Display



Overview

A large 16 character x 2 line LED display measuring 965mm x 163mm making it ideal for use in long corridors, nursing stations, staff rooms and offices.

Utilises the latest LED technology to visually inform staff of the location of incoming calls (and occupied rooms) in large, easy-to-read text.

All calls are displayed in red text except presence calls which are displayed in green.

When no calls are present on the system the current time is shown in green.

Typically used in conjunction with one or more standard QT608C displays as scroll and accept buttons ARE NOT included.

Mains powered.

Connects to Quantec via a QT615 display interface unit utilising a monitored RS232 data connection.

QT615S

Quantec Display Interface



Overview

Allows a QT608CD1S large corridor display to be connected to Quantec via an RS232 serial interface lead (supplied with the large display).

Mounts on a standard UK 20mm double gang flush or surface back box.

The data connection to the large display is monitored. If this is disconnected or the large display is switched off then the QT615S appears as Missing on the Quantec controller

For more information on these products, please contact us:



T: 00353 47 86274 / 00353 47 86663

E: Sales@irishsafetysystems.ie